

PIN-ON FRONT SIGHT INSTALLATION INSTRUCTIONS

Factory-installed pin-on front sights have varying hole locations, so our pin-on front sights are delivered undrilled.

To install a pin-on front sight in place of your existing pin-on sight, you or your gunsmith will need to drive the pin out of the existing sight. You will then place the new sight in your sight base, ensuring that it is fully seated, and using a #54 (.055 dia) drill bit, mark the sight, but do not drill through.

Remove the sight from the base, then lay the sight flat and drill through.

If you cannot find a #54 drill, you may use a 1/16" drill, and the enclosed 1/16" diameter x 1/4" long roll pin to replace your existing sight pin.



Protocall Design, LLC
8317 Lewis Drive
Rear
Lenexa, KS 66227
(913) 422-8966
sales@protocalldesign.com